

# *Route*

INDUSTRIAL  
AUTOMATION

*Route*

2500 AND 2700



CONTENTS

1.	GENERAL DESCRIPTION.....	2
2.	SETTING UP.....	3
	2.1 Initial Start Up.....	3
	2.2 Excitation supply.....	3
	2.3 Preamplifier.....	3
3.	CALIBRATION.....	4
	3.1 Procedure.....	4
	3.2 Zero Adjustment.....	4
	3.3 Gain Adjustment.....	4
	3.4 Display Adjustment LCD/LED.....	5
	3.5 Analog Output Adjustment.....	6
	3.6 Setpoint or Alarm Outputs.....	6
	3.7 Alternative Calibration Methods.....	6
	3.7.1 Simulation.....	6
	3.7.2 Without Known Masses.....	7
	Minimum Weights.....	7
	Loadcell Signal.....	7
4.	TECHNICAL SPECIFICATION.....	9
	4.1 Power Requirements....	9
	4.2 Supply to Loadcells.....	9
	4.3 Input Signals.....	9
	4.4 Voltage Output.....	9
	4.5 Current Output.....	9
	4.6 LED/LCD Display.....	10
	4.7 Alarm or Setpoint Relays.....	10
	4.8 BCD Output.....	10
	4.9 Zero Stability.....	10
	4.10 Span Stability.....	10
	4.11 Ambient Temperature Range.....	10
	4.12 Enclosure.....	10
	4.13 Protection Class.....	10
5.	SCHEMATICS.....	11
	5.1 2500/2700 Motherboard. ....	11
	5.2 2500 Display board.....	12
	5.3 2700 Display board.....	13
	5.4 Relay board.....	14

1. GENERAL DESCRIPTION

The ROUTE 2500 AND 2700 ARE low cost, high accuracy loadcell indicator/transmitters especially suitable for field mounted applications (IP65 enclosure).

These units have a four and a half digit LED (Route 2500) or LCD (Route 2700) display and offers retransmission signals of 0-10V and 4-20 mA as standard.

These units are fully self-contained only requiring a 110V or 220V AC supply. They provide a 10V excitation supply capable of supplying up to four load cells.

The whole instrument is fully enclosed in an alucast enclosure and suitable for harsh environments.



## 2. SETTING UP

### 2.1 Initial Start up

Before power is connected to the instrument, a visual check should be performed:

Check if the correct fuse (500ma) is inserted.

Check if the correct supply voltage is selected as per the jumper links:

JP4 jumper on the middle two pins ( 220 volts )

JP4 jumper on the pin 1 & 2 and 3 & 4 ( 110 volts )

JP5 Excitation jumper on the first two pins.

JP6 & JP7 must be in place.

Check if the connection from the main board to the display board is present ( ribbon cable )

Check the wiring carefully ( avoid loose connections )

If a 4-wire loadcell cable is used, check that jumpers JP6 JP7 are in place (behind loadcell connection terminal).

If a 6-wire loadcell cable is used, remove jumpers JP6 JP7.

Initial Measurement:

Connect a loadcell ( or loadcells ) and then:

\* Apply Power

\* Verify d.c supply voltage

\* Verify reference voltage

(+15 V dc  $\pm$  0,1 V measured between TP1 and TP2)

(-15 V dc  $\pm$  0,1 V measured between TP3 and TP2)

### 2.2 Excitation Supply

Adjust Potentiometer VRI to obtain an excitation voltage of 10 volt dc, measured between terminals 6 and 8. The excitation voltage can also be measured between TP4 and ground (TP2). This is factory preset to 10Vdc.

### 2.3 PreAmplifier

The input signal to the amplifier can be measured between terminals 10 (+) and 11 (-). For proper functioning of the instrument the following input signals should not be exceeded:

Live signal	( full scale )	minimum 3,3mV
		maximum 30mV
Tare signal		minimum 0mV
		maximum 14mV
Gross signals	( full scale )	minimum 3,3mV
		maximum 30mV

The amplified signal (gain of 30) is measured between TP5 and TP2

The gain of the preamplifier is determined by the ratio of R8:R9 and R10:R11 respectively. The standard values are: R8 = R10 = 1K, R9 = R11 = 330K

Should it be necessary to further increase the gain of the instrument, the values of R11 and R9 can be increased of the values of R11 = R9 and R8 = R10.

### 3. CALIBRATION

#### 3.1 Procedure

Calibration of the route 2700 is to be done in the following sequence:

1. Zero Adjustment
2. Gain Adjustment
3. Display Adjustment

#### 3.2 Zero Adjustment

After installation of the loadcells and initial setup (paragraph 2) the tare mass that needs to be zeroed is done as follows:

1. Adjust the course zero (rotary switch) SW1 until the display is closest to zero (hopper empty).
2. Adjust the fine pot VR2 until exactly zero is displayed.
3. Measure the voltage between TP6 and TP2 ( it should be 0,00 V ).

#### 3.3 Gain Adjustment

Load ( or simulate ) at least 50% of full capacity onto The weigh element and adjust the gain as follows (NB: Ignore the digital display at this stage) :

1. Measure the voltage between TP6 and TP2 (0-10 volts);
2. Calculate what portion of full capacity is applied (if full capacity is 10 t and only 5 t is applied, then adjustment is 50% of 10 V);
3. Turn rotary switch SW2 until closest reading to value determined in 2. is achieved ( e.g. 5 V);
4. Fine tune to exact value with potentiometer VR3.



### 3.4a Display Adjustment LCD

With the mass still loaded as described in the previous paragraph, follow the steps below to adjust the display:

1. Decide what engineering units, resolution and decimal point position is required;
2. Select the decimal position with SW2-3, 4, 5 or 6 on the display board;
3. Adjust rotary switch "Course Span" CODESW until the display is closest to the required value. Adjust span fine adjustment VR1. Span can be multiplied or divided by switching SW1 1 (UP divide DOWN multiplied)
4. Blank the last digit with SW1-2 if necessary;

Note: Under normal circumstances, do not exceed the resolution of the loadcells.

### 3.4b Display Adjustment LED

With the calibration mass still loaded as described in the previous paragraph, follow the steps below to adjust the display:

1. Decide what engineering units, resolution and decimal point position is required;
2. Select the decimal position with SW1-3, 4, 5 or 6 on the display board;
3. Adjust rotary switch "Course Span" CODESW until the display is closest to the required value. Adjust span fine adjustment VR1. Span can be multiplied or divided by switching SW1 1 (UP divide DOWN multiply).
4. Blank the last digit with SW2-2 if necessary;

Note: Under normal circumstances, do not exceed the resolution of the loadcells.

### 3.5 Analog Output Adjustment

The current (4-20mA) and/or voltage (0-10 V) outputs can now be fine tuned by connecting a multimeter in series to terminals 14 and 15 for current, or in parallel to 12 and 13 for voltage.

Adjust potentiometer VR4 for 4 mA ( current ) or 0,0 V.

Adjust potentiometer VR5 for 20 mA (current) or 10,0 v or a calculated portion as required.

JP8 jumper in = 4 - 20mA output.

JP8 jumper out = 0 - 20mA output.

Note: 4-20mA is preset. On a zero load (0 Volts across TP3 and TP6) 4mA will be present, while on full load (that is 10 Volts across TP3 and TP6) a 20 mV reading will be present.



### 3.6 Setpoint or Alarm Outputs - Relay Board

Decide on normally open or normally closed setpoints and connect up at the appropriate two positions on the motherboard (SEE 2500/2700 MOTHERBOARD Pg.12)

Ensure jumper jp1 on the motherboard is in position (bridged) before relay card is inserted.

Ensure jumper jp5 on the relay card is in position (bridged)

Select the appropriate position for jumper caps by choosing either pins 1 @ 2 for lo alarm and 2 @ 3 for hi alarms. Jumper jp6 is for relay 1, jumper jp7 for relay 2, etc.

#### TO SET:

Setting of the relays requires the use of a multi-meter.

-) Switch multi-meter to DC volts and test between TP5 (black probe) and TP1 (red probe)

2) To set relay 1, adjust VR1 to between 0 volts and -10 volts being 100% of full load.

3) to set relay 2, move red probe to TP2 and set VR2, etc.

Adjust JP6, JP7, JP8 and JP9 for normally on or normally off.

RELAY1=JP6

RELAY2=JP7

RELAY3=JP8

RELAY4=JP9

NOTE 1: One jumper position must always be selected, high or low level, otherwise the relays cannot be activated.

NOTE 2: If relay card is removed, JP1's jumper cap must also be removed from the motherboard to allow proper functioning of the ROUTE 2500/2700.

### 3.7 Alternative Calibration Methods

#### 3.7.1 Simulation

By simulating an input signal to the amplifier, zero and span adjustments can be done without using a live mass. Loadcell simulators are available for this purpose, but few of them offer an adjustable impedance. The total resistance of the simulator should be the same as the total resistance of the loadcells in use (e.g. 3 \* 350ohm loadcells = 116,7 ohms).

If a 350 ohm simulator is used, it can be connected in place of one of the loadcells with the other loadcells signal connections disconnected. This however only offers a 30% span adjustment (for a 3 loadcell system) as the signals are paralleled.



### 3.7.2 Without known masses.

Calibrating a weighing system with known masses is the most accurate method to use. The system can be checked for repeatability and linearity to within the accuracy of the loadcells in use.

However, it is not always possible to handle 200, 50, or even 10 tons of test weights! Two procedures can be followed to calibrate such systems.

#### 1. using minimum test weights:

E.g. use 1 ton test weights and calibrate the system to 1 ton. Remove the 1 ton of weights and fill the vessel with make - up material such as product or water. Replace the 1 ton of weights calibrate for 2 ton. Repeat until 50% of maximum capacity is calibrated. This procedure is tedious and might be impractical for large hoppers.

#### 2. Utilising the loadcell signal and tare mass

Loadcells are linear transducers and their signals can be used to calibrate a system within reasonable accuracy.

Follow the steps below:

- a. Measure the excitation signal closest to the loadcells (i.e. at the field junction box). Record "EXC V"
- b. With the weight element empty, first disconnect the loadcell signal cables from terminals 10 and 11. Measure (0-10 mV) and record "EMPTY mV".
- c. Connect the signal cables. Now short wires and zero system. Disconnect the short and the display will display the hopper's empty mass. Set the measured mV.  
Re-zero the system (display) via SW1 and VR2 on bottom board.



8.

- d. Use the following formula to calculate the nett mass:

$$\frac{\text{FULL mV} - \text{EMPTY mV}}{\text{EXC V} \times \text{SENSITIVITY}} \times \text{TOTAL LOADCELL CAPACITY} = \text{NETT MASS}$$

Where: "TOTAL LOADCELL CAPACITY" = Sum of the  
load cells in use (e.g. 3 X 10t=30t)

"SENSITIVITY" = Rated loadcell  
sensitivity or output (e.g. 2 mV/V)

- e. Connect the signal cables and adjust the gain and display as described earlier.
- f. Reset display to previous reading before gain was adjusted.



#### 4. TECHNICAL SPECIFICATION

##### 4.1 Power Requirement

- Supply voltage :  $230V \pm 10\%$  /  $110V \pm 10\%$
- Power requirement : Approximately 16VA

##### 4.2 Supply to load Cells

- Excitation voltage:  $10V \pm 1.0\%$ (adjustable)
- Load on excitation supply : 4 x 350 ohm cells  
in parallel 6 x 350  
ohm on special request
- Short circuit protection : Current limit at  
approximately 180mA

##### 4.3 Input Signals

- Live signal (range) : Min. 0 to 3.3mV  
Max. 0 to 30mV
- Tare signal : Min. 0mV. max 14 mV
- Gross signal : Min. 3.3mV, max. 30mV

##### 4.4 Voltage Output

- Range : 0 to 10V
- Maximum current : 10 mA

##### 4.5 Current Output

- Range : 4 to 20mA Jumper JP8 Cap on  
0 to 20mA Jumper JP8 Cap off
- Max. loop Res. : 1000 ohm

##### 4.6a LED Display (for the Route 2500)

- Readout :  $4\frac{1}{2}$  digit (last digit blanking option)
- Independent span adjustment
- Character height : 15 mm
- Decimal point : Switch selectable pos.



#### 4.6a LCD Display (for the Route 2700)

- Readout :  $4\frac{1}{2}$  digit (last digit blanking option)
- Independent span adjustment
- Character height : 25 mm
- Decimal point : Switch selectable pos.

#### 4.7 Alarm or Setpoint Relays (Optional)

Four independent adjustable setpoint relays

- potential free contacts : 220V AC 2A

NB! JP1 must be bridged (jumper cap on) when two or 4 relay card is installed.

#### 4.8 BCD Output (only available on Route 2500)

- 1.5 digit parallel BCD code
- Run/hold mode facility.

#### 4.9 Zero Stability

- App. 0.05% / 10°C. max to full scale

#### 4.10 Span Stability

- App 0.05% / 10°C. max (input 20 mV)

#### 4.11 Ambient Temperature Range

- 10°C to 50°C.

#### 4.12 Enclosure



- Alucast
- 260mm x 160 mm x 90mm.

#### 4.13 Protection Class

- IP65.




# ROUTE 2500/2700 SCHEMATIC



LOADCELLS

# 2500/2700 MOTHER BOARD



## JUMPER SETTINGS

JMP	110V 1-2	240 3-4
JP1	110V 1-2	240 3-4
JP2	110V 1-2	240 3-4
JP3	110V 1-2	240 3-4
JP4	110V 1-2	240 3-4
JP5	110V 1-2	240 3-4
JP6	110V 1-2	240 3-4
JP7	110V 1-2	240 3-4
JP8	110V 1-2	240 3-4
JP9	110V 1-2	240 3-4
JP10	110V 1-2	240 3-4
JP11	110V 1-2	240 3-4
JP12	110V 1-2	240 3-4
JP13	110V 1-2	240 3-4
JP14	110V 1-2	240 3-4
JP15	110V 1-2	240 3-4
JP16	110V 1-2	240 3-4
JP17	110V 1-2	240 3-4
JP18	110V 1-2	240 3-4
JP19	110V 1-2	240 3-4
JP20	110V 1-2	240 3-4
JP21	110V 1-2	240 3-4
JP22	110V 1-2	240 3-4
JP23	110V 1-2	240 3-4
JP24	110V 1-2	240 3-4
JP25	110V 1-2	240 3-4
JP26	110V 1-2	240 3-4
JP27	110V 1-2	240 3-4
JP28	110V 1-2	240 3-4
JP29	110V 1-2	240 3-4
JP30	110V 1-2	240 3-4
JP31	110V 1-2	240 3-4
JP32	110V 1-2	240 3-4
JP33	110V 1-2	240 3-4
JP34	110V 1-2	240 3-4
JP35	110V 1-2	240 3-4
JP36	110V 1-2	240 3-4
JP37	110V 1-2	240 3-4
JP38	110V 1-2	240 3-4
JP39	110V 1-2	240 3-4
JP40	110V 1-2	240 3-4
JP41	110V 1-2	240 3-4
JP42	110V 1-2	240 3-4
JP43	110V 1-2	240 3-4
JP44	110V 1-2	240 3-4
JP45	110V 1-2	240 3-4
JP46	110V 1-2	240 3-4
JP47	110V 1-2	240 3-4
JP48	110V 1-2	240 3-4
JP49	110V 1-2	240 3-4
JP50	110V 1-2	240 3-4
JP51	110V 1-2	240 3-4
JP52	110V 1-2	240 3-4
JP53	110V 1-2	240 3-4
JP54	110V 1-2	240 3-4
JP55	110V 1-2	240 3-4
JP56	110V 1-2	240 3-4
JP57	110V 1-2	240 3-4
JP58	110V 1-2	240 3-4
JP59	110V 1-2	240 3-4
JP60	110V 1-2	240 3-4
JP61	110V 1-2	240 3-4
JP62	110V 1-2	240 3-4
JP63	110V 1-2	240 3-4
JP64	110V 1-2	240 3-4
JP65	110V 1-2	240 3-4
JP66	110V 1-2	240 3-4
JP67	110V 1-2	240 3-4
JP68	110V 1-2	240 3-4
JP69	110V 1-2	240 3-4
JP70	110V 1-2	240 3-4
JP71	110V 1-2	240 3-4
JP72	110V 1-2	240 3-4
JP73	110V 1-2	240 3-4
JP74	110V 1-2	240 3-4
JP75	110V 1-2	240 3-4
JP76	110V 1-2	240 3-4
JP77	110V 1-2	240 3-4
JP78	110V 1-2	240 3-4
JP79	110V 1-2	240 3-4
JP80	110V 1-2	240 3-4
JP81	110V 1-2	240 3-4
JP82	110V 1-2	240 3-4
JP83	110V 1-2	240 3-4
JP84	110V 1-2	240 3-4
JP85	110V 1-2	240 3-4
JP86	110V 1-2	240 3-4
JP87	110V 1-2	240 3-4
JP88	110V 1-2	240 3-4
JP89	110V 1-2	240 3-4
JP90	110V 1-2	240 3-4
JP91	110V 1-2	240 3-4
JP92	110V 1-2	240 3-4
JP93	110V 1-2	240 3-4
JP94	110V 1-2	240 3-4
JP95	110V 1-2	240 3-4
JP96	110V 1-2	240 3-4
JP97	110V 1-2	240 3-4
JP98	110V 1-2	240 3-4
JP99	110V 1-2	240 3-4
JP100	110V 1-2	240 3-4


ROUTE:  
MODEL:  
2700/2500  
REV: 01

20 mA adjustment  
4 mA adjustment  
Fine gain adjustment  
Coarse gain adjustment  
Fine zero adjustment  
Coarse zero adjustment

SERIAL  
NUMBER



# 2500 DISPLAY



# 2500/2700 RELAY CARD

